

# **VERTIV**<sup>™</sup>

# Albér Universal Xplorer Industrial Monitor (UXIM)

## Firmware Release Notes

#### **VERSION 1.12.6**

#### **Release Notes Section Outline**

- 1 Updates for This Release (Version 1.12.6)
- 2 Version 1.11.1 Update Information
- 3 Version 1.08.04 Update Information
- 4 Version 1.07.02 Update Information
- 5 Version 1.06 Update Information
- 6 Version 1.05 Update Information
- 7 Version 1.03 Update Information
- 8 Version 1.02 Update Information

### 1 Updates for This Release (Version 1.12.6)

- Alarm enable and Alarm latch functions improved over MODBUS interface
- Boot log response time over network improved
- Changing the "Digital input" name over the network is now supported
- UXIM will show actual intercell resistance value on cell one when most negative mode selected
- The intermittent constant one volt reading is now removed
- With this release, the resistance test now does not stop when configurator connects to the device
- Unit will now automatically start scanning in 20 minutes if the unit is in maintenance mode

## 2 Version 1.11.1 Update Information

- Long discharges data corruption resolved
- Discharge delete commands now ignored during discharge
- Default baseline and resistance values added for factory default setting
- Resistance test disabled during discharge
- Scanning of reading is now always enabled during discharge
- · Complete baseline resistance readings are now recorded
- Ripple current alarm is now disabled for one hour after resistance test
- All alarms will reset before resistance test to prevent false alarms after test
- Support added for reverse cell conditions



## 3 Version 1.08.04 Update Information

- Intercell channel selection now available for current measurement
- Support added for Internal resistance, intercell resistance and discharge current correlation factor
- Fixture configuration 1X24X2 (debugger software only) has been tested
- System time and date can now be set via MODBUS
- · Ground fault alarm detection reports are corrected
- · Ground fault switches are now turned off before measuring ripple current to improve reading accuracy

### 4 Version 1.07.02 Update Information

- · Start-up report now contains baseline date and time
- Discharge current alarm is now only checked when current is negative
- Alarm state is now checked when alarm thresholds are changed or enabled
- Only major alarms will activate device contact relays
- Added ability to clear the normalization timers
- Fixed resistance problem with continuous restarting due to RTC initialization

#### 5 Version 1.06 Update Information

- Calibration constraints are now prevented from getting erased occasionally
- · Alarm lights are corrected and now reflect the real alarms
- Improved how discharge data is capture to avoid corruption

#### 6 Version 1.05 Update Information

- Added support for two sets of alarms: Major (Warning) and Minor (Caution)
- · Added controls to disable, enable and latch both major and minor alarms
- Ambient temperature is now captured at the beginning and ending of discharge
- Capture time stamps added to reports for resistance tests, voltage and temperature
- · Fixed float alarm threshold resetting issue

### 7 Version 1.03 Update Information

- Added the ability to enable/disable ambient temperature settings using the MODBUS port [internal reference number 2539]
- Added a new feature to enable/disable ambient temperature [internal reference number 2531]
- Improved battery resistance readings by modifying the algorithm [internal reference number 2516]
- Added a new feature to report positive and negative ground fault voltages [internal reference number 2458]
- Disabled standalone functions when a battery monitor is connected to the UXCM [internal reference number 2348]
- The UXIM front panel will now flash all LEDs green during a resistance test [internal reference number 2344]
- The UXIM front panel will now flash all LEDs amber during a discharge [internal reference number 2343]
- Added support for ground fault measurements on positive and negative sides of the graph on the UXIM application software [internal reference number 2258]
- Added support for the UXCM protocol over fiber optical (USART0) [internal reference number 2245]



## 8 Version 1.02 Update Information

- Added an extra 10ms before performing a string current reading; the extra time allows the signal channel to settle down [internal reference number 2141]
- Added an extra 10ms time delay for response of MODBUS over RS-484; the extra time delay allows communications with the devices [internal reference number 2140]

<sup>© 2017</sup> Vertiv Co. All rights reserved. Vertiv and the Vertiv logo are trademarks or registered trademarks of Vertiv Co. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness herein, Vertiv Co. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications are subject to change without notice.